



WARNING – UPDATING THE FIRMWARE WILL RESTORE ALL DEFAULT SETTINGS AND ERASE THE MEMORY. ANY SETUP CHANGES, CALIBRATION, WI-FI, WEATHER SERVER AND MEMORY HISTORY DATA WILL ALL BE CLEARED. IT IS IMPORTANT TO BACKUP DATA BEFORE PROCEEDING WITH THE UPDATE IF YOU WISH TO KEEP YOUR WEATHER HISTORY FILES.


1. Unzip the file into SD card, it should be in the root file folder on SD card




Update EasyWeather contains following files:




2. Insert the SD card into console, and re-power up the console. Then you will see:



3. If the Update EasyWeather folder is found on SD card, installation automatically begins:



4. If update is successful the following message will appear:



5. Press any button to continue