

FST-201 Wind Speed Transmitter

Firstrate 



- Three cup mechanical wind speed sensor
- Digital circuits capable of strong RFI & EMI resistance
- Automatic temperature compensation
- All external parts made of powder coated alloy material
- Features good water proof and corrosion resistance
- Internally sealed to protect from water, salt, fog and dust
- Built-in electronic heating system, when temperature falls below 0°C system will automatically start heating to prevent icing of moving parts

Specification:

Output:	4-20mA three wire connection
Working Voltage:	5 ~ 36V DC
Range:	0.5m/s ~ 50m/s (180 km/h)
Starting Speed:	≤0.5m/s (1.8 km/h)
Accuracy:	±3% FS
Conditions:	Temperature: -20°C~+85°C / Humidity ≤95%RH
Maximum Speed:	70m/s for 30min
Connection:	M12 weather proof
Protection:	IP65

Distributor:

AWR Smith Process Instrumentation cc

PO Box 449 Pinegowrie 2123

Tel: 011 782 7279 / 888 7144 Fax: 086 648 7664

e-mail: sales@instruments.co.za website: www.instruments.co.za